

Canopy Cover Installation Instruction

- Place the canopy fabric bundle on top of the frame and unroll the canopy down the center of the frame.
- When completely unrolled, unfold the cover across the top of the canopy bows and pull down snugly over the frame.
- Make sure the canopy is centered on the frame with equal amounts of overhang on each side and on each end.
- The QuikLash black webbing should be on the inside, right behind or slightly above the aluminum canopy frame going lengthwise. This canopy uses individual bungees with a hook on the end.
- Attach each bungee through a perforated hole of the QuikLash webbing directly in-line with each canopy rib.
- Stretch the bungee underneath the canopy frame and up into the hole in the corresponding frame rib.
- Alternate from side to side and end to end to make sure the top does not become off centered.

